



Palm Nailer

MODEL
PC0701




- * Does not include seals
- * No incluye sellos de gomas
- * Ohne Dichtringe
- * Joints exclus

Questions? Comments? call SENCO's toll-free Action-line: 1-800-543-4596 or e-mail: toolprof@senco.com




1/4" F.P.T.

Available Plugs
(Not Included with Tool)



✓ PC0486



Ind. Interchange 1/4" MPT



✓ PC0474

Tru-Flate 1/4" MPT

✓ Recommended Plugs
Plugs shown smaller than actual size



	A	B
Non-Magnetic	FC0317	FA0168

PC0701 Palm Nailer

REPLACEMENT PARTS LIST • LISTA DE PARTES DE REPUESTO • LISTE DE PIÉCES DE RECHANGE

PART #	DESCRIPTION	DESCRIPCION	DESIGNATION
AB0083	HOUSING	ALOJAMIENTO	CORPS
AC0155	CAP	TAPA	BOUCHON
BA0126	CYLINDER ASSY.	ASEMBLE DE CILINDRO	ENSEMBLE CYLINDRE
BA0127	VALVE	VÁLVULA	VALVE
BA0128	SPACER	SEPARADOR	ENTRETOISE
BA0129	GASKET	ARANDELLA	JOINT
BA0131	SPRING	RESORTE	RESSORT
BB0160	BUMPER	AMORTIGUADOR	AMORTISSEUR
CB0022	VALVE SEAT	VÁLVULA ASIENTO	SIÈGE DE VALVE
CC0159	VALVE BUMPER	VÁLVULA AMORTIGUADOR	AMORTISSEUR DE VALVE
EC0291	PISTON DRIVER ASSY.	ASEMBLE DE PISTON PERCUSOR	ENSEMBLE PISTON-COUTEAU
FA0168	NOSE	NARIZ	NEZ
FA0200	GUIDE, MAGNETIC	GUÍA, MAGNETICA	GUIDE, MAGNÉTIQUE
FC0317	GUIDE	GUÍA	GUIDE
KB0040	SCREW	TORNILLO	VIS
LB0810	SEAL	SELLO	JOINT
LB0811	SEAL	SELLO	JOINT
LB0812	SEAL	SELLO	JOINT
LB0813	SEAL	SELLO	JOINT
LB0814	SEAL	SELLO	JOINT
LB0815	SEAL	SELLO	JOINT