

REPLACEMENT PARTS LIST  
 LISTA DE PARTES DE REPUESTO • LISTE DES PIÈCES DE RECHANGE

PART NO.	NOTES	DESCRIPTION	DESCRIPCIÓN	DÉSIGNATION
H0001		Handle	Mango	Poignée
H0013	quantity (4)	Screws/Washers	Tornillo/Arandela	Vis/Rondelles
H0033		Pins	Pasador	Tige de butée
H0036		Pin	Pasador	Goupille
H0037		Screw	Tornillo	Vis
H0038		Driver	Percusor	Tige de poussée
H0045		Spring	Muelle	Ressort
H0046		Guide	Guía	Guide
H0055		Feeder shoe assembly	Asamble de alimentador	Coulisseau
H0080		Hammer	Martillo	Marteau
H0084		Cap	Tapa	Caoutchouc
H0087		Block	Bloque	Bloc
H0108		Plastic base	Base de plástico	Semelle
H0118		Plunger	Émbolo	Piston
H0144		Plate	Placa	Plaque
H0150	includes H0055	Magazine	Cargador	Magasin
H0158		Retainer	Junta tórica	Caoutchouc de retenue
H0188	optional accessory	Plastic base for ½" flooring	Base plástico	Semelle pour planches de ½"
H0343		Guide body	Placa de nariz	Plaque guide
P0154		Grip	Agarradero	Gaine

In the U.S.A., you will find your nearest Senco location listed in the Yellow Pages under "Staples".  
 Or, you can call our toll-free Action-line: 1-800-543-4596

H0876; Revised March 30, 2006 (Replaces January 31, 1999) © 1999, 2006 Senco Products Inc., Cincinnati, Ohio 45244 - USA

# SENCO<sup>®</sup>

## SHF10

