




SN1

Parts Reference Guide

Made
in the
U.S.A. 




* Schematic Drawings inside



Model	A
14000 1N BF/TF	EB0006

* Does Not Include O-rings
 * No incluye sellos de gomas
 * Ohne Dichtringe
 * Joints exclus



REPLACEMENT PARTS LIST • LISTA DE PARTES DE REPUESTO • ERSATSTEILE-LISTE • LISTE DE PIÈCES DE RECHANGE

PART NO.	DESCRIPTION	DESCRIPCIÓN	BESCHREIBUNG	DÉSIGNATION
AA0029 MAIN BODY ASSY.			
AA0044 DETENT ASSY.			
AB0029 DETENT			
BA0007 PISTON ASSY.			
BA0008 CYLINDER SLEEVE ASSY.			
BA0042 CAP ASSY.			
BA0043 CAP ASSY.			
BB0005 DEFLECTOR			
BB0009 STOP			
BB0021 SPACER			
BB0036 VALVE			
BB0037 SPACER			
CA0062 CORE ASSY.			
CA0064 HOUSING ASSY.			
EB0003 DRIVER (REGULAR)			
EB0004 DRIVER (1/32" CSK.)			
EB0005 DRIVER (1/16" CSK.)			
EB0006 DRIVER (1/8" CSK.)			
EC0061 MAIN PISTON			
FA0006 GUIDE BODY ASSY.			
FA0007 BACKPLATE			
FA0008 GATE ASSY.			
FB0001 PIN			
FB0003 PLUG			
GA0005 FEEDER SHOE			
GA0006 MAGAZINE			
GA0007 BRACKET			
GB0003 RAIL			
GB0146 ROLLER OUTER			
GB0147 ROLLER INNER			
HA0002 SAFETY			
HB0002 BUSHING			
HB0007 TRIGGER			
HB0008 TRIGGER SAFETY			
HB0009 TRIGGER (RESTRICTIVE)			
HB0010 BUSHING (RESTRICTIVE)			
HB0043 PIN			
HG0055 LABEL (SAFETY PRECAUTIONS)			
HG0127 LABEL (SAFETY PRECAUTIONS)			
KA0005 PIN			
KB0154 SCREW			
KB0288 SCREW			
KB0443 SCREW			
KB1550 PIN			
KB1551 PIN			
KB1596 PIN			
KB1636 PIN			
KB2714 NUT			
KB2966 WASHER			
KB4029 SPRING			
KB5004 SCREW			
KB5005 SPRING			
KB5007 SCREW			
KB5011 SPRING			
KB5037 SCREW			
KB5191 SPRING			
LB0011 SEAL			
LB0014 SEAL			
LB0021 SEAL			
LB0027 SEAL			
LB0030 SEAL			
LB0034 SEAL			
LB0071 SEAL			
LB0079 SEAL			
LB0295 SEAL			
LB3217 SEAL			
LB3224 SEAL			
LB5004 SEAL			
MB5006 ADAPTER			